

Installation Instructions

- Hurricane Turbo 998 Intake Adaptor



1 - Remove the stock plastic turbo intake pipe from sled

2 - Measure 1" from the BOV as indicated in the picture



3 - Sand the casting imperfections off the pipe from the new edge to about the nipple. This should allow a tight fit to work the Hurricane Turbo 998 Intake Adaptor to index it for proper clearance to the steering shaft and alignment with the turbo inlet. Test fit the adapter aligning the boss on the adapter with the seam on the intake tube.



4 - Apply a good plastic glue to the inlet tube (such as JB Plastic)

5 - Install the adaptor and align the rotation so that the raised boss on the adaptor lines up with the seam on the intake tube.



6 - Install back onto the sled and clamp the supplied silicone coupler to the turbo and the adaptor. You may find it easier to slip the coupler on to the adaptor first, then fit the assembly to the turbo. For added ease in installing, you might want to remove the two nuts holding the steering post in place so it can be moved for more clearance. Some sleds will have the coolant hose that is directly above the adaptor placed quite far down on the coolant tube that the adaptor runs under. It is suggested that this hose be moved out near the end of the coolant tube coming off the engine to allow more clearance for the adaptor. When correctly installed the reliefs in the adaptor will be positioned for clearance around the coolant tube and the steering post. The far end of the intake tube will line up just outside the inner edge of the clutch cover. Tighten all clamps and steering post nuts if removed.

